


4

3

2

1



P415 UPPER RECEIVER COMPONENTS BY DESCRIPTION

REVISION DATE: 08/26/2020

4

3

2

1

4

3

2

1

00937

00935

COMPLETE ASSY
00345 (STANDARD)
00782 (RATTLER)
00813 (ARCHANGEL)
00849 (TOMAHAWK)
01542 (STRIKE EAGLE)

01011 SCREW

01010 KIT

00936

00934

00559 (ASSEMBLY)
00938 (COMPONENT)

00940

00307

00954

00565

RECEIVER ONLY ("STRIPPED")
00133 (BLACK)

00922

00949

00952

00932 (THREADED INSERT)

RECEIVER SUB ASSY
00069 (BLACK)

00923

00945

00943

00895

00947

00929

00930

00927

00563

00925

00926

00147 (KIT)

00328 (ASSEMBLY)
00941 (COMPONENT)

00749

00919

00918

00914

00308 (BRAKE - SHOWN)
00870 (FLASH HIDER)

P415 UPPER RECEIVER COMPONENTS BY SKU NUMBER

REVISION DATE: 08/26/2020

4

3

2

1

D

D

C

C

B

B

A

A